

LIFTING CUSHION: C.B.P

Read these instructions in full before use

PRECAUTIONS FOR USE:

Temperature range for use: - 20 to + 55°C.

Avoid any contact with very abrasive or sharp surfaces.

Stabilise and guide the load to be lifted.

Do not place the hand or any part of the body between the load and the cushion in use.

Never stand beneath the raised load. Keep away when the cushion is in use.

For inflating and deflating, use only the filling and connection systems stated by Pronal.

Never exceed the maximum pressures indicated on the product of 0,5bar.

If the feed pressure exceeds the working pressure, use a pressure reducer.

Full safety equipment should be worn when using the cushion (helmet, safety glasses, ear protectors, safety boots, protective clothing and gloves).

For any contact with chemicals, please consult us.

USE:

These lifting cushions can be inflated with exhaust gas or any other inflation system.

Use handling handles to move the cushion.

The low thickness of the cushion allows easy insertion under load.

Positioning is facilitated by the markings on the cushion.

Insert the cushion parallel to the surface of the load to be lifted.

Operate the cushion by monitoring the movements of the load.

Superposition of cushions

This use is possible only on the CBP 3 and CBP 5 only.

In this case, side loops allow the passage of a composite ring ensuring the overlay.

A maximum of 2 cushions may be stacked. To perform the raising operation, the lower cushion, which is used as a base, is fully inflated and then the upper cushion is inflated with care. **Never start inflating the upper cushion while the lower cushion is deflated.** Lowering is achieved by proceeding in reverse order: first, deflate the upper cushion before starting deflating the lower cushion. **Never deflate the lower cushion either before or at the same time as the upper cushion.**

Respect strictly the working travel limits indicated on the product. Please contact us for all technical data.

SERVICING:

After each use: visual inspection

- Check the integrity of the external surface and check for the absence of any excessive deformation (creases, bubbles or cuts). In case of doubt or the appearance of a fault, you are advised to consult the manufacturer before reusing.
- Clean the product (using slightly soapy water without detergent), rinse and dry out the whole product thoroughly.

At least once a year: operation test

Inflate the lifting cushion with care to a pressure of 0.5 bar. Check the absence of defects (cracking, cuts etc.). If no damage is detected, increase the pressure to 4 bar and repeat the check.

In case you doubt about the safety (detection of a defect etc.), do not use the product any more and contact the manufacturer.

For safety reasons, repairs are not possible.

STORAGE:

This product must be stored:

- Deflated after each use
- Flat in its packing
- Away from light
- At ambient temperature and humidity conditions of between 40% and 70%.
- Away from any potential sources of damage (corrosive agents and vapours, solvents, marine environment, rodents...)

MAINTENANCE :

When taking down, check the integrity of the exterior surfaces, the tubing/bladder connection and the flatness of the gasket surface at the stem.

**"KEEP YOUR ENVIRONMENT CLEAN"**

For the disposal of wastes generated at the end of life, respect the laws and regulations of your country. Contact the appropriate organism for recovery and waste treatment

A PRONAL TEAM IS AT YOUR DISPOSAL TO ASSIST YOU WITH ANY INSTALLATION. PLEASE CONTACT US.

